

Stealth S-Line : How to Replace Paper



1. Tilt (push) the display backward.



2. Push the lever to open the printer cover.



3. Replace paper roll, and pull paper to extend outside the printer.



4. Close printer cover, and resume operation.